




Dual Mono Jumper Settings




XLR Pin 1 Ground Jumper Settings





Mic Pre In/Out Jumper Settings



Mic Sensitivity Settings



Phantom Voltage Settings




Set Programming Jumpers For:

- Push-To-Talk Logic
- XLR Pin 1 Grounding
- Dual Mono Send
- Power-Up State
- Phantom Voltage
- Mic Gain
- Mic Pre In/Out

Remote Barrier Strip

- Pin 1 Audio On/Off Input (pull to Gnd)
- Pin 2 Relay n.o. (audio not muted)
- Pin 3 Relay n.c. (audio muted)
- Pin 4 Relay Common
- Pin 5 Audio Output +
- Pin 6 Audio Output -
- Pin 7 Chassis Ground
- Pin 8 Ground
- Pin 9 -15VDC
- Pin 10 +15VDC

Push On/Push Off Jumper Settings



Part # **SH-MICPTTPLUS** StudioHub+ Mic Preamp Panel
with selectable mic preamplification and push-to-talk logic